

RETAIL wash and maintenance



**GTI MAX – Attraction – Creation 70 – Design Tile – Urban Tile
LVT – Taralay impression – Creation Zen – Linoleum - Mipolam**



Floor Washing Machine

Red 3M pad or medium hard brush.

Daily cleaning with a neutral floor cleaner (see manufacturer recommendations)

Important!

Correct mixing ratio of water/cleaner, in cold/lukewarm water

Set the floor cleaning machine to high water dosage

Max speed for the floor cleaning machine is 3.5 km/h (slow walking)

Change pads/brushes according to instructions. Pad after 20,000 m² = approx. after 4 weeks. brushes when there are visible signs of wear.

Check suction/wiper blade so the floor is almost dry after the machine

For heavy soiling, soak the floors in floor deep cleaner for at least 10 minutes. Adjust the size of the work area so the floor does not dry out. Then wash the floor as you would for daily cleaning.



Manual Cleaning

Coarse Microfiber Mop.

Use red 3M doodlebug for the edges the machine cannot reach.

Daily cleaning with a neutral floor cleaner (see manufacturer recommendations)

Important!

Correct mixing ratio of water/cleaner, in cold/lukewarm water

Leave the floor "almost" dry

For heavy soiling, soak the floors in floor deep cleaner for at least 10 minutes. Adjust the size of the work area so the floor does not dry out. Then wash the floor as you would for daily cleaning.

It is important to empty and clean the floor washing machine after use.

Change the microfiber mop when it is dirty (after 5 – 7 m² of washing)

»See the list of manufacturer-recommended cleaning products«

VÄHITTÄISMYNNIN pesu ja huolto



**GTI MAX – Attraction – Creation 70 – Design Tile – Urban Tile
LVT – Taralay impression – Creation Zen – Linoleum - Mipolam**



Lattianpesukone

Punainen 3M pad tai keskikova harja.

Päivittäinen pesu neutraalilla lattianpesuaineella (katso valmistajan suositukset)

Tärkeää!

Oikea sekoitussuhde vesi/pesuaine, kylmässä/haaleassa vedessä

Aseta lattianpesukone korkealle vedenannostelulle

Lattianpesukoneen maksiminopeus 3,5 km/h (hidas kävely)

Vaihda pad/harjat ohjeiden mukaan. Pad 20 000 m² jälkeen = noin joka 4. viikko

Tarkista imu/pesulasta niin, että lattia on lähes kuiva pesukoneen jälkeen

Raskaassa likaantumisessa liota lattiat lattian syväpuhdistusaineessa vähintään 10 minuuttia. Säädä työalueen kokoa niin, että lattia ei kuivu. Pese sitten lattia kuten päivittäisessä puhdistuksessa.



Manuaalinen pesu

Karkea mikrokuitumoppi

Käytä punaista 3M doodlebugia reunoihin, joihin pesukone ei pääse

Päivittäinen pesu neutraalilla lattianpesuaineella (katso valmistajan suositukset)

Tärkeää!

Oikea sekoitussuhde vesi/pesuaine, kylmässä/haaleassa vedessä

Jätä lattia "melkein" kuivaksi

Raskaassa likaantumisessa liota lattiat lattian syväpuhdistusaineessa vähintään 10 minuuttia. Säädä työalueen kokoa niin, että lattia ei kuivu. Pese sitten lattia kuten päivittäisessä puhdistuksessa.

On tärkeää tyhjentää ja puhdistaa lattianpesukone käytön jälkeen.

Vaihda mikrokuitumoppi, kun se on likainen (5–7 m² pesun jälkeen).

»Katso valmistajan suosittelema puhdistusaineiden luettelo«